


# Calling Overview

Place/receive calls to/from WILLCOM handsets, landlines and other mobiles.

- Calling charges vary depending on the other party's device type, etc. For details, contact WILLCOM Service Center.



## Signal Conditions

Confirm signal strength and Battery charge beforehand.



### Battery Charge

More bars indicate greater charge.

### Signal Strength

More bars indicate stronger signal.

## Switching to Another Antenna for Better Reception

- Follow these steps:



## International Calls & Roaming

Place international calls from Japan on handset. (No separate subscription is required.)

- Handset is not available for placing/receiving calls outside Japan.

# Placing Calls

## Entering Number Directly


- 1 Enter number with area code → 



- Wait for receiver to accept the call.

- 2  → Call ends

### After Calls to Unsaved Numbers


- Save to Phone Book confirmation appears. Select **New Entry** or **New Detail** and press  to save number; new entry window or contact search window opens, respectively.

## Dialing from Call Log

- 1  (Received) or  (Diald)





- 2 Select record → 

- 3 
  - Wait for receiver to accept the call.

- 4  → Call ends

## Dialing from Phone Book

- 1  →  Select tab (hiragana row, alphabet or \*) for first character of last name



- 2 Select contact → 

- 3 Select number → 
  - Wait for receiver to accept the call.

- 4  → Call ends

## Placing Calls

### Placing International Calls

Place international calls easily through WILLCOM's international calling service.

- 1 Enter number →   
→ Int'l Call → 



- Country code list appears.




- 2 Select country code → 

- 3 


- Wait for receiver to accept the call.

- 4  → Call ends

### Direct Entry

- 1 Enter  (access number)

- 2 Enter country code (e.g., )

- 3 Enter number (with area code) → 

- Omit the first 0 of the number except when calling some countries/regions.
- Wait for receiver to accept the call.

- 4  → Call ends

# Answering Calls

## Answering Calls

- 1 When a call arrives...



- Incoming Call window opens.

- 2



- Call connects.

- 3


 → Call ends

## When You Cannot Answer

### Placing Calls on Hold

- 1

When a call arrives,  →

- Call connects while the call is on hold.
- Press  to answer the call on hold.

### Recording Caller Messages



- 1

When a call arrives,  →

**Record Message** → 

- Answer Phone is set.

### Playing Messages



 → Select record → 

# Engaged Call Operations

## Adjusting Earpiece Volume

- 1 During a call, 

## Muting Microphone


- 1 During a call, 
  - Press  again to cancel.

## Recording Caller Voice





- 1 During a call, 






- 2 **Voice Record** 

- Recording starts. To stop, press .

## Playing Recorded Messages






  Select record  

## Sending Touch Tone Signals

- 1 During a call, 
  - ➔ **Dial number**  

- 2 **Enter touch tone digits**
  - Touch tone signal is sent.

## Sending Touch Tone Signals via Phone Book

After 1,   **Send Tone by**  
**Phonebook**    Select contact   
  Select number  