

# Safety Precautions







Read Safety Precautions before using handset.

- Observe precautions to avoid injury to self or others, or damage to property.
- We are not liable for any damages resulting from use of this product.

These labels show degree of risk from improper use; learn them before reading on:

 <b>DANGER</b>	Great risk of death or serious injury
 <b>WARNING</b>	Risk of death or serious injury
 <b>CAUTION</b>	Risk of minor injury or damage to property

These symbols signify prohibited/compulsory actions; learn them before reading on:

 Prohibited	Prohibited actions
 Do Not Disassemble	Disassembly prohibited
 Avoid Liquids Or Moisture	Exposure to liquids prohibited
 Do Not Use Wet Hands	Use with wet hands prohibited
 Compulsory	Compulsory actions
 Disconnect Power Source	Unplug from outlet

## Safety Precautions

### Handset, Battery, AC Charger (Optional Accessory) & Memory Card (Sold Separately)



#### Use specified Battery and AC Charger only.

Non-specified equipment use may cause Battery to leak, overheat, burst or ignite, and may cause AC Charger to overheat, ignite, malfunction, etc.



#### Do not disassemble, modify or solder handset or related hardware.

May cause fire, injury, electric shock or malfunction. Battery may leak, overheat, burst or ignite. Modifying handsets is prohibited by the Radio Law and subject to penalty.



#### Do not expose handset or related hardware to liquids.

Do not let exposed handset/related hardware remain wet; do not charge wet Battery. May cause overheating, electric shock, fire, injury or malfunction. Use only as directed.



#### Do not charge Battery in or expose handset or related hardware to extreme heat (fire, heat sources, direct sunlight, inside vehicles, etc.). Do not charge, leave, use, or be carrying handset or related hardware in a warm place or where heat collects, such as under a kotatsu (blanketed warming table) or electric blanket, next to a kairo (worn warming patch), etc.

May cause warping/malfunction; Battery may leak, overheat, ignite or burst. Handset or related hardware may become hot to the touch, leading to burn injuries, etc.



#### Do not force Battery/AC Charger into handset. Confirm terminal/connector orientation; retry.

Battery may leak, overheat, burst, ignite, etc.



#### Do not place handset, Battery or AC Charger in/on ovens, microwave ovens, pressure cookers, induction stoves or other cooking appliances.

Battery may leak, overheat, burst or ignite. Handset/AC Charger may overheat, emit smoke, ignite, malfunction, etc.



## Safety Precautions

**Keep handset off and AC Charger disconnected near gas stations or places with fire/explosion risk.**

Handset use near petrochemicals or other flammables may cause fire/explosion.



Compulsory

**Do not drop/throw or subject to strong impact.**

Battery may leak, overheat, burst or ignite, resulting in fire, electric shock, malfunction, etc.



Prohibited

**For unusual sound/odor, smoke or other abnormality:**

Continued use may cause fire, electric shock, etc.; grasp AC Charger plug to disconnect from the outlet, power off, then remove Battery, being careful not to burn or injure yourself.



Compulsory

**Keep liquid (water, pet urine, etc.) or conductive material (pencil lead, metal strip/jewelry, etc.) away from External Device Port.**

May cause short circuit, resulting in fire, malfunction, etc.



Prohibited



### CAUTION

**Do not place handset or related hardware on unstable surfaces.**

Handset or related hardware may fall, resulting in injury, malfunction, etc.; take added care when Vibration is set or while charging.



Prohibited

**Keep handset and related hardware out of infants' reach.**

Infants may choke from swallowing handset or related hardware or be injured, etc.



Compulsory

**For use of handset/related hardware by child, explain instructions and supervise use.**

Misuse may cause injury, etc.



Compulsory

## Handset



### WARNING

**Do not use handset while driving or cycling.**

Accidents may result. Phone use while driving or cycling is prohibited by law and subject to penalty; park legally beforehand.



Prohibited

**Power off near electronic devices that employ high precision control systems or weak signals.**

May cause electronic malfunctions, etc. Take added care near these devices: Hearing aids, implanted pacemakers/defibrillators and other electronic medical equipment; fire alarms, automatic doors and other automatic control devices.



Compulsory

## Safety Precautions

---

**Keep handset off aboard aircraft or in hospitals, etc. where mobile phone use is prohibited.**



Compulsory

Handset use may affect electronic medical equipment and other electronic devices. For mobile phone use in medical facilities, obey corresponding medial facility rules. Conducting prohibited acts such as using mobile phone aboard aircraft is subject to penalty by law. However, if mobile phone use aboard aircraft is allowed under certain conditions (signal transmitting functions are disabled, etc.), follow airline instructions.

**Users with a heart condition should adjust ringtone Vibration and Volume as needed.**



Compulsory

**If thunder is audible while outdoors, power off; find cover.**



Compulsory

There is a risk of lightning strike or electric shock.

**Do not look into Infrared Port during Infrared transmissions.**



Prohibited

Eyesight may be affected.



**CAUTION**

**Do not use handset when it may affect a vehicle's electronic equipment.**



Prohibited

Handset use inside vehicles may cause electronic equipment to malfunction, resulting in accidents.

**For any skin irritation associated with use, discontinue use and consult a doctor.**



Compulsory

Metal and other materials (P.12-3) may cause skin irritation, rashes, or itchiness depending on your physical condition.

**Keep handset away from magnetic cards, etc.**



Prohibited

Data on bank cards, credit cards, telephone cards, floppy disks, etc. may be lost.

**Do not swing handset by Strap.**



Prohibited

May harm self or others; Strap may break, resulting in injury or handset malfunction/breakage.

**Handset may become hot while in use, especially in high temperature.**



Compulsory

Prolonged contact with skin may cause burn injuries.

**Always maintain some distance from Speaker while ringtones, music or other handset sounds play.**



Prohibited

Excessive volume may damage ears or hearing.

**Keep fingers, Straps, etc. outside when opening/closing handset.**



Compulsory

May cause injury, breakage, etc.

**Moderate handset Volume when using Headphones.**



Compulsory

Excessive volume may damage ears or hearing.

## Safety Precautions

### Battery

Read Battery label to confirm battery type; use/dispose of Battery accordingly.

Symbol on Label	Battery Type
Li-ion00	Lithium-ion

### DANGER

**Do not dispose of Battery in fire.**

Battery may leak, burst, ignite, etc.



Prohibited

**Do not damage (nail, hammer, stomp, etc.) Battery or subject it to strong impact.**

Battery may leak, overheat, burst, ignite, etc.



Prohibited

**Keep wire or other metal objects away from Battery terminals. Do not carry/store Battery with conductive material (pencil lead, metal strip/jewelry, etc.).**

Battery may leak, overheat, burst, ignite, etc.



Prohibited

**If battery fluid gets in eyes, do not rub; rinse with water and consult a doctor immediately.**

Eyes may be severely damaged.



Compulsory

### WARNING

**If battery fluid contacts skin or clothes, discontinue handset use and rinse with clean water immediately.**

May cause skin damage.



Compulsory

**If Battery does not charge properly, stop trying.**

Battery may leak, overheat, burst, ignite, etc.



Compulsory

**For abnormal odor, excessive heat, discoloration or distortion, remove Battery, being careful not to burn or injure yourself. Avoid sources of flame.**

Continued use may cause Battery to leak, overheat, burst, ignite, etc.



Compulsory

**Keep Battery away from pets.**

Pet bites may cause Battery to leak, burst, overheat, ignite, etc.



Compulsory

### CAUTION

**Do not dispose of an exhausted Battery with ordinary refuse.**

Battery may ignite or damage the environment. Insulate Battery by taping over Battery terminals before disposal. Take Battery to a WILLCOM Plaza/WILLCOM Counter, or follow the local disposal regulations.



Prohibited

## Safety Precautions

### AC Charger (Optional Accessory)



#### WARNING

**Do not cover/wrap AC Charger while charging.**

AC Charger may overheat, resulting in fire, malfunction, etc.



Prohibited

**Use only the specified voltage.**

Non-specified voltages may cause fire, malfunction, etc.

- AC Charger: AC 100 V - 240 V Input

Do not use power adapters. Transformer use may cause fire, electric shock or malfunction.



Prohibited

**Unplug AC Charger for periods of disuse; grasp plug to disconnect.**

May cause electric shock, fire or malfunction.



Disconnect Power Source

If liquid (water, pet urine, etc.) gets inside, grasp plug to disconnect it immediately.

May cause electric shock, smoke or fire.



Disconnect Power Source

**To remove debris, grasp plug to disconnect AC Charger, then clean with a dry cloth.**

Fire may result.



Compulsory

**Plug AC Charger firmly into the outlet, keeping plug and terminals away from conductive material (pencil lead, metal strip/jewelry, etc.).**

May cause electric shock, short circuit, fire, etc.



Compulsory

**Do not touch plug with wet hands.**

May cause electric shock, malfunction, etc.



Do Not Use Wet Hands

**Do not touch AC Charger if thunder is audible.**

May cause electric shock, etc.



Prohibited



#### CAUTION

**Grasp plug to disconnect AC Charger before cleaning.**

May cause electric shock, etc.



Disconnect Power Source

**Always grasp plug (not cord) to disconnect AC Charger.**

Pulling plug by cord may damage cord; may cause electric shock, fire, etc.



Compulsory

**Do not subject AC Charger to strong impact while it is plugged in.**

May cause malfunction or injury.



Prohibited

## Safety Precautions

---

### Handset Use & Electronic Medical Equipment

This section is based on "Guidelines on the Use of Radio Communications Equipment such as Cellular Telephones and Safeguards for Electronic Medical Equipment" (Electromagnetic Compatibility Conference, April 1997) and "Report of Investigation of the Effects of Radio Waves on Medical Equipment, etc." (Association of Radio Industries and Businesses, March 2001).



### WARNING

Persons with implanted pacemaker/defibrillator should keep handset more than 22 cm away.

Radio waves may interfere with implanted pacemakers or defibrillators.



Compulsory

Before using electronic medical equipment other than implanted pacemaker/defibrillator outside medical facilities, consult the vendor on radio wave effects.

Radio waves may interfere with electronic medical equipment.

Observe these rules inside medical facilities to avoid effects of radio waves on electronic medical equipment:

- Do not enter an operating room or an Intensive or Coronary Care Unit while carrying a handset.
- Keep handset off in hospitals.
- Even in lobbies or other places, keep handset off near electronic medical equipment.
- Obey medical facility rules on mobile phone use.



Compulsory



Compulsory

Power off in crowds or trains where persons with implanted pacemaker/defibrillator may be near.

Radio waves may interfere with implanted pacemakers or defibrillators causing such devices to malfunction.



Compulsory

# General Notes

---

## General Use

- We are not liable for any damages resulting from accidental loss/alteration of handset/Memory Card files or settings. Keep separate copies of contacts, etc.
- Handset transmissions may be disrupted inside buildings, tunnels or underground, or when moving into/out of such places; may affect calls.
- Use handset without disturbing others.
- Handsets are radios as stipulated by the Radio Law. Under the Radio Law, handsets must be submitted for inspection upon request.
- Handset use near landlines, TVs or radios may cause interference.
- For proper usage of Memory Card, read the manual beforehand.

## • Beware of eavesdropping.

Because this service is completely digital, the possibility of signal interception is greatly reduced. However, some transmissions may be overheard.

- Deliberate/accidental interception of communications constitutes eavesdropping.
- Beware of harmful/malicious websites. Take added care when posting personal information, etc.
- An export license may be required to carry handset into other countries if it is to be used by or transferred to another person. However, no such license is required when taking handset abroad for personal use on a vacation or business trip and then bringing it back. Export control regulations in the United States provide that an export license granted by the US government is required to carry handset into Cuba, Iran, North Korea, Sudan or Syria.

## Handset & Hardware Care

- Handset is not water proof. Avoid moisture.
  - Keep handset away from precipitation.
  - Cold air from air conditioning, etc. may condense causing corrosion.
  - Avoid leaving handset in damp places (restroom, bath/shower, etc.).
  - On the beach, keep handset away from water and direct sunlight.
  - Perspiration may get inside handset causing malfunction.
- If handset is left with no Battery inserted or an exhausted one, files and data may be altered/lost. We are not liable for any resulting damages.



## General Notes

---

- Use handset within 5°C - 35°C and 35% - 85% humidity.
- Avoid extreme temperature or direct sunlight.
- Handset/Battery may become warm during operation or while charging. This is normal.
- Warranty does not cover malfunctions resulting from misuse.
- Exposing Camera area to direct sunlight may damage Color Filter and affect image color.
- Battery may not charge properly if Port/terminals are obstructed by dust, etc. Clean with a dry cloth, cotton swab, etc.
- Clean handset with a soft dry cloth. Alcohol/solvent use may fade color/print.
- Avoid scratching Display.
- Avoid heavy objects or excessive pressure. May cause malfunction or injury.
  - Do not sit on handset in back pants pocket.
  - Do not place heavy objects on handset inside handbags, packs, etc.
- Connect only specified products to External Device Port. Other devices may malfunction or cause damage.
- Always power off before removing Battery. If Battery is removed while saving data or sending mail, data may be lost, changed or destroyed.
- Do not power off while using Memory Card; may result in data loss or malfunction.
- When walking outside, moderate handset Volume to avoid accidents.
- Avoid covering Speaker while using handset.

## Camera

- Mind etiquette when using Camera.
- Test Camera before shooting special moments.
- Do not use Camera in places where shooting is prohibited.
- Captured images may not be used/transferred without copyright holder (photographer, etc.) permission, except for personal use.