## **Using Call Services**

#### **Using Voicemail**

Divert all/unanswered calls to Voicemail Center; access messages afterward.

- A separate subscription is required.
- Not available when Call Forwarding is set.
- Message playback charges apply for playing messages.

#### ■Initiating/Canceling Voicemail







• Service Center menu opens.

Call Forwarding Center

- You will be connected to the center for service settings.
- Follow voice guidance (Japanese).

### ■ Accessing Messages via Notices

After a message is stored at Voicemail Center, handset receives Light Mail from Voicemail Center (Caller ID: **070-696-1000**).

After a message is stored...




Information window opens.

Voicemail → •



- You will be connected to Voicemail Center.
- Follow voice guidance (Japanese).

#### **■**Checking for Messages



After hearing a beep, 💿

• Voicemail appears when a message is stored.

#### 

- You will be connected to Voicemail Center.
- Follow voice guidance (Japanese).

### **Using Call Forwarding**

Divert all/unanswered calls to a preset phone number.

- No separate subscription is required.
- You will be charged for the forwarded part of the call.
- Not available when Voicemail is set.
- Initiating/Canceling Call Forwarding



Service Center → •



Service Center menu opens.

3

# Call Forwarding Center (143) → •

- You will be connected to the center for service settings.
- Follow voice guidance (Japanese).

#### **Using Split Billing Service**

Have two separate bills issued for calls placed from handset. Charges for calls placed using Split Billing service will be billed to preset secondary billing contact.

- A separate subscription is required.
- Split Billing service does not apply to Light Mail transmission or Internet use (and messaging).
- ■Calling via Split Billing Service
- Enter phone number with area code ▶ □
- 2 Split Bill → •
  - Wait for receiver to accept the call.